




OPUSTM / OPUSATM

.50 Caliber Semi-Automatic Paintball Marker

USER MANUAL

English
Français



OPUS™

OPUS A™

.50 Caliber Semi-Automatic Paintball Marker

TABLE OF CONTENTS

IMPORTANT SAFETY GUIDELINES	1
OPERATION GUIDE/START UP	2
8 STEPS TO START AND PLAY	3-4
CO2/COMPRESSED AIR TANK WARNINGS	5
INSTALLING A CO2/COMPRESSED AIR TANK	5-6
PROPER USE OF YOUR BARREL BLOCKING DEVICE	6
INSTALLING/REMOVING A PAINTBALL LOADER	6
VELOCITY ADJUSTMENT INCREASE/DECREASE	7
A JAMMED PAINTBALL IN THE BREACH	7
HOW TO CLEAN THE MARKER	7-8
DISASSEMBLE/REASSEMBLE AND CLEANING OF REAR INTERNALS	8-9
CUP SEAL REMOVAL GUIDE	9-10
TROUBLESHOOTING	10
OPUS™ / OPUS A™ PARTS LIST	11
OPUS™ / OPUS A™ SCHEMATIC	12
WARRANTY STATEMENT	13

IMPORTANT SAFETY GUIDELINES



WARNING

- This paintball Marker is NOT a toy. Misuse can cause serious injury or death.
- Kingman recommends that the customer be at least 18 years of age to purchase this product. Person under 18 years of age must have adult supervision when using this product.
- Read this User manual before using this product.
- Any modifications or tampering of original factory parts or use non authorized aftermarket accessories will void all warranties and liabilities from Kingman.
- Keep the barrel blocking device on Marker when not shooting/playing.
- To ensure proper adjustment of velocity Feet Per Second (fps), Kingman strongly recommends using a chronograph for paintball use located or purchased at most paintball stores and paintball fields. The discharges of paintballs are high velocity and high impact that can cause serious injuries or death if misused.
- Before/after use of the Marker, check and make sure all screws are securely tightened. Loose screws may prevent the Marker from functioning properly. A paintball Marker NOT properly maintained can be dangerous and can cause serious injury or death.
- Any person using this product or within range of this product while it is in use MUST wear EYES/FACE, EARS PROTECTION designed specifically for the sport of paintball. This includes, but is not limited to, performing a maintenance/velocity check and during target practice.
- Kingman reminds the user that SAFETY IS YOUR RESPONSIBILITY. Protect your eyes/face and ears at all times, and will not be held liable for injuries or death sustained when failing to follow the safety guidelines.
- Never shoot or point your Marker at a person that is not in a designated paintball facility and without proper paintball EYES/FACE/EARS PROTECTION. The protection includes and not limited to the protection of eyes, face, ears, neck and head. Avoid shooting underneath the paintball goggles.
- DO NOT point or shoot at any Law Enforcement Officer.
- Treat every paintball Marker as if it were loaded.
- Never look down the barrel of a loaded or unloaded Marker.
- Always keep the paintball Marker in SAFE MODE until ready to operate.
- Always remove the air source and all paintballs from the Marker, includes paintballs inside the breach of the Marker, before disassembly.
- Fire only .50 caliber paintballs with this product. The use of any foreign objects will VOID all warranties and liabilities from Kingman.
- Always make certain the bolt of the Marker is in the un-cocked position when not shooting/playing.
- Using a paintball Marker outside of a non designated paintball field can be illegal, and is subject to law enforcement penalties if property damage is caused by the user.
- Never point or shoot your Marker at an animal.
- Never point the barrel toward yourself while playing, running or stumbling to avoid shooting underneath your paintball goggles.
- Wear appropriate dress to avoid any exposure of skin to protect you when playing paintball games.
- Transfer this User's Manual upon change of Marker ownership.
- Please visit www.spyder50.com for the latest User Manual updates.

OPERATION GUIDE / START UP

1. Always attach a barrel blocking device over the tip of the barrel for safety precautions when not shooting/playing.
2. Kingman recommends having the Marker in the SAFE MODE position before use. To operate, push the safety button from the "PUSH SAFE" side of the Trigger Frame. This will position the Marker in a lock SAFE MODE. To disengage the safety button in a safely manner, point the Marker in a safe direction, and push the safety button towards the opposite side of the Trigger Frame. **CAUTION:** Do not disengage safety button until step 6.
3. Attach a CO2/Compressed Air Tank to the Markers C/A adapter. Using a CO2/Compressed Air Tank firmly tighten clockwise to the Markers C/A adapter until it is snug. **HELPFUL TIP:** Make sure to have the CO2/Compressed Air Tank filled before attaching. **NOTE:** O-rings in the Markers parts kit are NOT supplied to attach with a CO2/Compressed Air Tank. **IMPORTANT:** You should never need to use any hand tool to attach a CO2/COMPRESSED AIR TANK to the Markers C/A adapter. (SEE CO2/COMPRESSED AIR TANK WARNING)
4. Attach the paintball loader to the Markers clamping feed neck and tighten the set screw. **NOTE:** Fill your paintball loader with only .50 caliber paintballs.
5. Cocking the Marker. Pull the Top Cocking Knob rearward until the Venturi Bolt latches. **CAUTION:** Should you let go of the Top Cocking Knob before it latches, your Marker may fire.
6. Remove the barrel blocking device over the barrel. Now you can release the safety button. **CAUTION:** With the safety button released in the FIRE position the Marker is ready to shoot/play. By pulling the Trigger will fire a paintball. **IMPORTANT:** Only test your Marker in a safe direction or in a designated playing field.
7. Performing a velocity (fps) check. Turning the Velocity Adjuster/Spring Guide clockwise will increase the velocity (fps) while turning counter-clockwise will decrease the velocity (fps). **NOTE:** Your Marker is intended to be used in a paintball facility with the proper paintball protection. **IMPORTANT:** Kingman recommends using a chronograph to ensure Marker's velocity is under 300 (fps).
8. When finished playing, remove all paintballs from the loader then detach the loader from the Markers feed neck by loosening the set screw on feed neck clamp. **CAUTION:** There may be one paintball in the Marker's breach; take a shot or two in a safe direction to make sure the barrel and Receiver are empty.
9. Place the barrel blocking device over the barrel tip. This will help avoid any accidental discharge.
10. Kingman recommends having the Marker in the SAFE MODE and un-cocked position after use.
11. Unscrew the CO2/Compressed Air Tank from the Markers C/A adapter. By turning the tank counter clockwise will detach from the Markers C/A adapter. **CAUTION:** Never expose any skin underneath the C/A adapters bleed hole when removing the tank. This can run the risk of getting skin burn from the releasing of the GAS. **IMPORTANT:** You should never need to use any hand tool to detach a CO2/Compressed Air Tank from the Markers C/A adapter. (SEE CO2/COMPRESSED AIR TANK WARNING)
12. Store the Marker in a paintball bag or in a safe place. **WARNING:** Before/after use of the Marker, make sure to fasten all screws. Loose screws may prevent the Marker from functioning properly. **HELPFUL TIP:** It's a good practice to lubricate your Marker before and after each use, especially when storing the Marker for an extended period of time. Add a few drops of paintball gun oil on the Striker O-ring (SEE DISASSEMBLE/ REASSEMBLE AND CLEANING OR REAR INTERNALS). Before storing the Marker, make sure the Marker is in the SAFE MODE, un-cocked position without air source attached, any paintball inside the Marker has been removed and with barrel blocking device on.

IMPORTANT


- Firing velocity may vary according to altitude and climate conditions.
- It may be dangerous approximately within 300 feet (100 meter) of shooting range.
- Before using your Marker in play, you must always first perform a "SAFE VELOCITY TEST". This can only be accomplished by using a testing device called a "Velocity Chronograph" and can be performed at a paintball dealership or local playing field. **NOTE:** This product is intended to be used at a velocity no greater than 300 feet per second (fps). Paintball Markers are not intended to shoot within 30 feet.
- This paintball Marker may have excess gas after the removal of the CO2/Compressed Air Tank. Please remove all paintballs and discharge the remaining gas safely.
- Never store a CO2/Compressed Air Tank attached on the Marker.

8 STEPS TO START AND PLAY

IMPORTANT: Please read the Safety and Operation Guidelines before you start the 8 quick steps to Start and Play.



Make sure the safety is ON



Insert the barrel blocking device



**Put on your paintball goggles and
cock back the marker**



Remove the barrel blocking device



Install a CO2/Compressed air tank



**Install a paintball loader and add
paintballs in the loader**




Unlock the safety




Ready to play fire

IMPORTANT: Make sure the Marker is in the SAFE MODE and the barrel blocking device is on the Marker's barrel after PLAY.

CO2 / COMPRESSED AIR TANK WARNINGS



SAFE



WARNING: UNSAFE



DANGER

The CO2 or Compressed Air Tank can fly off with enough force to cause serious injury or death if the Valve unscrews from the cylinder head. LOOK at the Valve when removing the cylinder from the marker. Be sure that the valve is turning with the cylinder rather than remaining stationary with the marker. STOP if the Valve starts to unscrew from the cylinder. If in doubt, screw the cylinder back onto the marker and contact a trained person for repair.

CO2 / COMPRESSED AIR TANK WARNINGS

- All valves must only be installed or removed by a qualified airsmith.
- See CO2 / Compressed Air tank labels for retest dates. Cylinder tanks must be retested periodically.
- Improper use, filling, storage or disposal of all air cylinders may result in death, personal injury and/or property damage.
- Always keep cylinders out of reach from children or any inexperienced person(s).
- Only properly trained personnel in accordance with CGA Pamphlets P.1 and G-6.3 must fill all air cylinders. Pamphlets are available from the Compressed Gas Association or www.CGANET.com.
- Never alter the cylinder in any way.
- DO NOT expose pressurized cylinders to temperatures in excess of 130 °F (54 °C).
- Cylinders heated to an excess of 250 °F (121 °C) must be condemned or requalified in accordance with test defined in CFR-49.
- The valve should NEVER be detached from the canister. Please seek immediate assistance from a trained airsmith should this occur.
- Any tank packed with the product is intended for paintball use only.
- Confirm that there is an attached urethane O-ring on the CO2 / Compressed Air tank valve before attaching the tank to the marker. The tank will leak air as soon as it is secured to the marker, if the O-ring is missing from the valve.
- A urethane O-ring is highly recommended before attaching any air supply to the marker.
- NEVER over pressurize a CO2 / Compressed Air cylinder.
- Avoid any direct skin exposure to the escaping gas, when installing or removing any air supply.
- Never expose cylinders to corrosive materials or clean with any caustic cleaners.

INSTALLING A CO2 / COMPRESSED AIR TANK

Firmly screw the CO2 / Compressed Air Tank clockwise into the markers C/A Adapter. **HELPFUL TIP:** Before installing a CO2 / Compressed Air Tank, make sure that the tank is full and that it has a urethane bottle on the top of the valve to prevent air leaks.

IMPORTANT: You should never need to use any hand tool to attach a CO2 / Compressed Air Tank to the C/A Adapter.

REMOVING A CO2 / COMPRESSED AIR TANK

Firmly unscrew the CO2 / Compressed Air Tank by turning the tank counter-clockwise until it comes out of the C/A Adapter. **HELPFUL TIP:** After firing the marker, you should ALWAYS remove the CO2 / Compressed Air Tank before storing. When the tank is being removed, excess air will release from the C/A Adapter. **CAUTION:** Never expose any skin to the C/A Adapters bleed hole when removing the tank. This is to avoid the risk of getting skin burn from the escaping GAS.

IMPORTANT: You should never need to use any hand tool to detach a CO2 / Compressed Air Tank from the C/A Adapter. If you cannot remove a tank by hand please see a certified airsmith for assistance.

PROPER USE OF YOUR BARREL BLOCKING DEVICE

A Barrel Blocking Device or "BBD" is an essential part of your paintball safety equipment. The Barrel Blocking Device is designed to stop a paintball from exiting a paintball marker accidentally. Improper use of the Barrel Blocking Device will render this device useless.

BARREL SOCK/BAG TYPE DEVICE

Place the bag/sock part of the Barrel Blocking Device over the end of your barrel and wrap the elastic cord around the back end of your marker.

Adjust the length of the elastic cord to make sure your Barrel Blocking Device fits securely over your markers barrel.

NOTE: If the elastic cord is too long you can tie a couple of knots around the cord to shorten its length.

BARREL PLUG TYPE DEVICE

Insert the barrel plug securely into the end of your markers barrel before proceeding to load paintballs and screwing in your tank to your marker.

The barrel plug should fit firmly into the barrel with a significant amount of resistance. **NOTE:** The barrel plug should not be easy to remove and always inspect the O-rings to make sure they are not worn or cut.


Remove the Barrel Blocking Device only when you are getting ready to begin play or have been instructed to do so by a field safety official.

Always keep your Barrel Blocking Device on your marker after you have finished playing. Keep it in place even after you have emptied all paintballs and removed your air tank from your paintball marker.

WARNING:

- Inspect your Barrel Block Device regularly for wear and any tear if it is worn, replace it immediately.
- Always have your Barrel Blocking Device in place on your markers barrel to insure safety and prevent accidents that may cause permanent injury or even death.


INSTALLING/REMOVING A PAINTBALL LOADER



Attach an electronic or gravity paintball loader to the Markers Feed Neck and tighten the set screw. Only use .50 caliber paintballs through the loader.

Loosen the Feed Neck set screw and remove the electronic or manual paintball loader. When removing the loader make to remove all paintballs. **CAUTION:** There may be paintballs in the Markers breach; take a couple of shots in a safe direction to make sure the barrel and Receiver are empty.

VELOCITY ADJUSTMENT INCREASE / DECREASE



To INCREASE your velocity (fps) using the Allen wrench, turn the Velocity Adjuster/Spring Guide clockwise.

To DECREASE your velocity (fps) using the Allen wrench, turn the Velocity Adjuster/Spring Guide counter-clockwise. **HELPFUL TIP:** Allen wrench is provided in the spare parts kit. **NOTE:** The Velocity Adjuster/Spring Guide doesn't remove from the rear of the Striker Plug.

NOTE: The velocity of this paintball Marker ranges from approximately 220 - 300 feet per second (fps). Velocities will fluctuate or vary due to paintball size, climate condition, altitude, type of air source and variance in spring tension from manufacturing.

WARNING

- The recommended Velocity speed should be no greater than 300 fps. Not doing so can cause serious injury if the Velocity is dangerously high.
- Paintball markers are not intended to shoot any person less than 30 feet.
- Never point a loaded marker at any person who is not wearing the proper face protection.
- Never at any point should you look down the barrel, whether the marker is loaded or not.
- Using a paintball marker outside a non designated paintball field can be illegal, and is subject to law enforcement penalties if property damage is caused by the user.

A JAMMED PAINTBALL

In the event of a paintball break and the Venturi Bolt jams, follow these steps to help un-jam the Marker. The Markers breach is located where the barrel starts to thread in the Receiver and underneath the Markers feed neck. Before attempting to un-jam the Venturi Bolt you should always have your Goggles or Safety Glasses on. Make sure the Marker is in the SAFE MODE position before attempting to un-jam the Venturi Bolt. Remove the CO2/Compressed Air Tank before attempting to un-jam the Marker. Remove all paintballs and the loader from the feed neck. Have the barrel removed from the Receiver to allow the paintball(s) to exit. With enough force on the Cocking Knob, pull back to release the Venturi Bolt from the jammed position. Another method is to use a "Straight Shot Squeegee" or the end of a wood dowel rod; push against the face of the Venturi Bolt with enough force to release the jammed Bolt. Always clean the paint from the breach and barrel to enhance the performance of your Marker.

DANGER: Never look down the barrel of the Marker when loaded or unloaded. Remove the attached CO2/Compressed Air Tank before attempting to un-jam the Venturi Bolt. **NOTE:** Never use a metal rod or screwdriver as a tool to push on the Venturi Bolt, anything metal will scratch and damage the inside of the Marker.

HOW TO CLEAN THE MARKER

DANGER: Do not look down the Marker barrel. Always wear goggles specifically designed for paintball use while working on your paintball Marker.

IMPORTANT: Always have the Marker on SAFE MODE before disassembly. Remove all paintballs and air source from the Marker before performing any maintenance.

HELPFUL TIP: Follow these steps to help clean/remove Marker parts should in the event of a paintball break.

SQUEEGEE CLEANING OF THE BARREL AND BREACH (not included)

Using a Stick Squeegee (not included)


If the Venturi Bolt is in the un-cocked position you need to re-cock the Marker. Slide a stick squeegee down the barrel until it reaches the Markers breach. Then remove the stick squeegee out of the barrel. This should wipe clean any paint residue that could have broken inside the Marker. **HELPFUL TIP:** Make sure the Markers breach is clean

and clear of any paintball shell fragments or dirt. Repeat this step if the paint residue did not wipe clean after the first attempt.

Using a Cable Swab Squeegee (not included)

Twist off the barrel and slide a cable swab squeegee from the threaded end so the swab is the last portion of the squeegee out of the barrel tip. Grab hold the tail of the cable squeegee and pull. This should wipe clean any paint residue that could have broken in the barrel. **HELPFUL TIP:** Make sure the Markers breach is clean and clear of any paintball shell fragments or dirt. Repeat this step if the paint residue did not wipe clean after the first attempt.

DISASSEMBLE/REASSEMBLE AND CLEANING OF REAR INTERNALS



Part Names and Numbers describe in this section:

Top Cocking Knob (#STK010)
Venturi Bolt (#VTB050)
Striker Bolt (#STB003)
Striker Spring (#SPR017)

Striker Buffer (#STF002)
Striker Plug (#STP050)
Velocity Adjuster (#VTA050)
Receiver (#REC050/051/052/053)

Quick Clean Disassembly

Lift upward on the Top Cocking Knob to disconnect the Venturi Bolt from the Striker Bolt. This will allow the Venturi Bolt to slide out from the rear of the Receiver. **HELPFUL TIP:** Removing the Venturi Bolt from the Receiver will allow easy access to clean with a squeegee. **NOTE:** Make sure the hole on the Striker Bolt is facing upright when looking thru the Receiver. This will allow the Top Cocking Knob to correctly fasten with the Striker Bolt.

IMPORTANT: The air passage hole located in the middle of the Venturi Bolt should always be facing downward when reinstalling. If the Venturi Bolt is not installed correctly, paintballs will not exit out of the barrel normally.

Disassemble Of Rear Internals

STEP 1 Lift upward on the Top Cocking Knob to disconnect the Venturi Bolt from the Striker Bolt. This will allow the Venturi Bolt to slide out from the rear of the Receiver.



STEP 2 With a firm grip on the Striker Plug, turn the Striker Plug counter-clockwise to remove. This will allow all internal parts such as the Velocity Adjuster/Spring Guide, Striker Spring, Striker Buffer and Striker Bolt to slide from the rear of the Receiver. **NOTE:** Remove the Striker Plug only with the Marker in the un-cocked position this will prevent the internals from springing out because the Striker Spring is compressed.

STEP 3 Remove items in order; Striker Plug, Velocity Adjuster/Spring Guide, Striker Spring and Striker Buffer.

STEP 4 Slide the Striker Bolt out of the rear of the Receiver. **HELPFUL TIP:** When the internals are removed it would be wise to clean any dirt or paint from the inside of the Receiver with a squeegee and wipe the Venturi Bolt clean with a rag or paper towel. Apply some paintball gun oil on Striker O-ring periodically.

IMPORTANT: It is not necessary to disassemble the rear internals for basic maintenance unless the Striker O-ring needs to be replaced.

Reassembly Rear Internals



STEP 1 Reinsert the Striker Bolt with Striker O-ring facing toward the front of the Marker with the flat spot of the Striker Bolt facing down. **NOTE:** Apply thumb pressure behind the Striker Bolt and at the same time pull on the Trigger. Repeat this process until the Striker Bolt is fully inserted. **NOTE:** The hole on the Striker Bolt should be facing upright when looking thru the Receiver. **NOTE:** The images above display the Venturi Bolt "connected" to and "disconnected" from the Striker Bolt.

STEP 2 Insert the Striker Buffer flush with the Receiver and place the Striker Spring thru the Striker Buffer.


STEP 3 Tighten firmly the Striker Plug, Velocity Adjuster/Spring Guide to the rear of the Receiver.

STEP 4 Insert the Venturi Bolt thru the rear of the Receiver with the Top Cocking Knob. Press downward on the Top Cocking Knob to gain entry with the Striker Bolt hole. **NOTE:** If the Striker Bolt hole is not aligned upright, the Top Cocking Knob will not fasten correctly.

WARNING: Before/after use of the Marker, make sure to fasten all screws. Screws may become loose due to vibration. Loose screws can be dangerous and cause injury.

To assure that the Marker is assembled properly, follow the schematic drawing or position parts in order during disassembly. Parts assembled backwards or improper parts installed will/can cause the Marker to malfunction.

CUP SEAL REMOVAL



Part Names and Numbers describe in this section:

C/A Adapter (#ASAO26)
Vertical Screw (#SCR031)
Vertical O-ring (#ORG025)
Vertical Adapter (#VRT036)
Cup Seal (#ITP020)
Valve Pin (#ITP021)
Valve Spring (#SPR018)
C/A Adapter Screw (#SCR019)
Front Plug (#LPC050)
Foregrip Expansion Chamber (#FRG036)

STEP BY STEP CUP SEAL ACCESS

Access of the cup seal for service or replacement requires the removal of the Front Plug and Vertical CA Adapter.

STEP 1 Unscrew the CA Adapter screws and twist off the Foregrip and Foregrip Adapter from the Vertical Adapter.

STEP 2 Remove the Vertical Adapter by unscrewing the Vertical Adapter Mounting Screw, be sure to keep a finger over the Front Plug to prevent it from springing out. **NOTE:** The Front Plug and Vertical CA Adapter are both held in place by the Vertical CA Adapter Mounting Screw.

STEP 3 Pull the Front Plug out and it should come out with the Valve Spring, Cup Seal Guide, Cup Seal and Valve Pin all together.

STEP 4 Unscrew the Cup Seal from the Valve Pin and replace with the spare provided with your spare parts kit.

STEP 5 Follow the previous steps in reverse to re-install all components properly. Make sure the Front Plug screw hole is lined up with the vertical adapter screw hole.

IMPORTANT: Always make sure all air sources have been removed from your marker and any residual air has been vented out completely before servicing your marker. **NOTE:** Service or replacement of the Cup Seal should only be done if a leak is present and can be heard from the breach after the removal of the Venturi Bolt.

TROUBLESHOOTING

Dealing with a Paintball Breakage:

1. If the weather temperature is below 59°F (15°C) or above 86°F (30°C) paintballs can become brittle and not hold up to the Markers velocity and outside temperature. Paintballs have a shelf life and can become too fragile for use. Paintballs can take a different shape in time so would be wise to size the paintball with your barrel. Dirt or broken paint shell fragments in the barrel can cause the Marker to have re-cocking issues. Using a squeegee thru the upper portion of the Receiver will remove most of the dirt or broken shell fragments.
2. If the loader has double fed a paintball in the barrel/breach and the Marker was fired. This can break paint out of the barrel.
3. If you over shoot the paintball loader and in middle travel have wedged a paintball in the breach this could cause a paintball breakage.
4. Velocity adjustment is too high and needs to be lowered to proper velocity (fps) speed.

Recocking Related Issues

1. Need lubrication on the Striker O-ring. (SEE DISASSEMBLE/REASSEMBLE AND CLEANING OR REAR INTERNALS).
2. Striker O-ring is damaged or missing. Replace with a new Kingman approved Striker O-ring. **NOTE:** The Striker O-ring can not be substituted with another type of o-ring.
3. The pressure in the tank is too low and possibly needs to be refilled.
4. Dirt or broken paint shell fragments in the Receiver can cause the Marker to have recocking issues. Using a squeegee thru the upper portion of the Receiver will remove most of the dirt or broken shell fragments. Should this issue continue, remove the Markers internals for complete cleaning. (SEE DISASSEMBLE/REASSEMBLE AND CLEANING OR REAR INTERNALS).

DEALING WITH AN AIR LEAK

Down The Barrel Or Out Of The Trigger Frame

1. Cup seal is bad and needs to be replaced. (SEE CUP SEAL REMOVAL GUIDE)
2. The Valve Body lip is nicked or scratched and needs to be replaced. **NOTE:** Never remove the Valve Body unless specific repairs are needed.
3. Air leaking through the Receiver and out of the Trigger Frame. The back o-ring on the Valve Body is damaged and needs to be replaced.

Air Leak From The Hose Line


1. If air is leaking from the opposite ends of the hose fittings will need to retighten to snug.
2. The female end of the hose must have a plastic washer installed inside the hose collar and be tightened properly. **IMPORTANT:** The hose line supplied has metric female ends. This will not install into American 1/8" (NPT) threaded fittings. If installed incorrectly, it is possible to damage the attachment fittings and hose line.
3. The o-ring on the top of the foregrip has a torn o-ring or needs to be replaced. **HELPFUL TIP:** You can use a urethane bottle o-ring for replacement if not able to replace with a stock o-ring.

OPUS™ / OPUS A™ PARTS LIST

ASA026	C/A Adapter (matte black)	SAB001	Safety Button
BAR051	Spyder Barrel Plug (.50 cal)	SAB002	Safety Button A
BAR050	1PCS Barrel (matte black) (.50 cal)	SCR002	M4 x 8 Screw (A) A
BLS036	Detent Cover (plastic)	SCR016	M5 x 12 Screw w/ washer (A) A
BLS050	Ball Stopper (.50 cal)	SCR017	M5 x 12 Screw (allen big head)
FND051	Clamping Collar (matte black) (.50 cal)	SCR018	M3 x 8 Screw (+)
FND050	Feed Neck (matte black) (.50 cal)	SCR019	M5 x 28 Screw C/A Adapter Screw (A)
FRG036	Foregrip Expansion Chamber (matte black)	SCR030	M4 x 12 Clamping Screw (A)
GRP003	Rubber Grip Cover (black)	SCR031	M6 x 16 Vertical Screw (A)
HSE011	Disconnect Hose (male x female) 4.5"	SCR032	M4 x 6 Ball Detent Screw (A)
HSF004	Plastic Washer	SCR033	M6 x 8 Valve Body Screw (A) (.50 cal)
HSF009	90° Male to Male Adapter (std x met) swivel	SER002	Sear (semi)
ITP020	Cup Seal (.50 cal)	SPR008	Sear Spring (semi)
ITP021	Valve Pin (.50 cal)	SPR011	Trigger Spring (semi)
ITP022	Valve Body (.50 cal)	SPR017	Striker Spring (.50 cal)
LPC050	Front Plug (matte black) (.50 cal)	SPR018	Valve Spring (.50 cal)
ORG002	O-ring #15 80	STB003	Striker Bolt (.50 cal)
ORG004	O-ring #11 80	STF002	Striker Buffer (.50 cal)
ORG025	Vertical O-ring #10 80	STK010	Top Cocking Knob (semi) (.50 cal)
ORG026	Striker O-ring #12.54 70 pu (.50 cal)	STP050	Striker Plug Threaded (matte black) (.50 cal)
ORG027	O-ring #14 80 (.50 cal)	TRF003	Polymer Trigger Frame
ORG028	Barrel O-ring #14 70 (.50 cal)	TRF004	Aluminum Trigger Frame A
* PAK009	Spare Parts Kit (.50 cal.)	TR5003	Double Trigger (semi)
REC050	Opus Receiver (blue)	VBTO03	Bolt Locking Bearing
REC051	Opus Receiver (grey)	VBTO04	Bolt Locking Spring
REC052	Opus-A Receiver (black) A	VBTO13	Bolt Locking Screw
REC053	Opus-A Receiver (green) A	VBTO50	Bolt w/ Locking Knob (.50 cal)
RPN004	Trigger Roll Pin (large)	VRT036	Vertical Adapter (matte black)
RPN005	Sear Roll Pin (med)	VTAO50	Velocity Adjuster & Spring Guide (matte black) (.50 cal)
RPN006	Secondary Roll Pin (small)		

* Item Not Pictured (+) Cross-head Screw (A) Allen-head Screw **A** OPUS-A

OPUS™ / OPUS A™ SCHEMATICS



WARRANTY STATEMENT

Kingman warrants the original retail purchaser that this Marker is free from defects in material and workmanship under normal use and service for a period of (1) year from the original date of purchase. Kingman agrees to repair or replace (at its discretion) any product within a reasonable period of time. This warranty does not cover o-rings, cup seals, scratches, nicks, normal wear and tear of parts, any modifications, normal fading of anodizing and damage caused by dropping or hitting of this product. This warranty shall not apply if it is shown by a Kingman Technician that the consumer caused the defect or malfunction because of misuse. This warranty only covers original factory parts. Any modifications or tampering of original factory parts will VOID warranty and liabilities from Kingman. Any damage caused by water will not be covered under warranty. Warranty repair can only be conducted by Kingman Technician or Kingman Authorized Technician. For warranty to be effective, consumer must return the enclosed warranty registration card filled out, along with a copy of the purchase receipt, within (15) days of the original purchase date. This warranty is not transferable (paintball Markers are non-refundable). This warranty will NOT cover pick up, shipping, delivery, and/or house calls. If product needs repair, consumer please package it carefully and send together with your name, address, phone number and a brief description of the malfunction to:

KINGMAN GROUP

Attn: Tech Department
 14010 Live Oak Avenue
 Baldwin Park, CA 91706 U.S.A.
 www.kingman.com

» Warranty Registration is also available at www.spyder50.com

FOR TECHNICAL SUPPORT


Our Technical Support Department is open Monday through Friday, from 8 am to 5 pm (PST), and may be reached at Tel: (626) 430-2300 Fax: (626) 851-8530

PATENT PENDING

Spyder .50 Caliber recommends the use of the Spyder Slate™ .50 Caliber Paintballs and the Rapid™ E-Loader for Optimum Performance.



THE NEXT CHAPTER IN PAINTBALL.™



OPUS™
 OPUSA™

Marqueur de Paintball de Calibre .50

TABLE DES MATIERES

IMPORTANTES CONSIGNES DE SECURITE	17
MISE EN ROUTE	18
8 ÉTAPES POUR COMMENCER À JOUER	19-20
CONSIGNE DE SECURITE SUR LA BOUTEILLE DE CO2/AIR COMPRIME	21
INSTALLATION DE LA BOUTEILLE DE GAZ	21-22
UTILISATION APPROPRIÉE DU BOUCHON DE CANON	22
INSTALLATION/RETRAIT D'UN CHARGEUR DE BILLES	22
REGLAGE DE LA VELOCITE, AUGMENTER / DIMINUER	23
BILLE COINCEE DANS LA DESCENTE DE BILLE	23
NETTOYAGE DU MARQUEUR	23-24
DEMONTAGE/REMONTAGE ET NETTOYAGE DES PIECES INTERIEURES ARRIERES	24-25
ACCÈS AU JOINT DE CULASSE ÉTAPE PAR ÉTAPE	25-26
DÉPANNAGE	26
LISTE DES PIECES DU OPUS™ / OPUS A™	27
SCHEMA ECLATE DU OPUS™ / OPUS A™	28
POLICE DE GARANTIE	29

IMPORTANTES CONSIGNES DE SECURIT



WARNING

- Ce lanceur de paintball n'est pas un jouet, il peut provoquer des blessures grave voir la mort.
- Kingman recommande que le client soit agé d'au moins 18 ans pour acheter ce produit.
- Lisez le manuel attentivement et les précautions d'emploi de la bouteille d'air avant d'utiliser ce produit.
- Toute modification du produit ou de ses pièces d'origines entraînera l'annulation de la garantie ainsi que la responsabilité de Kingman.
- Kingman recommande d'utiliser un bouchon de canon quand le lanceur n'est pas utilisé.
- Pour s'assurer de la vélocité du lanceur kingman recommande fortement d'utiliser un chronographe spécifique au paintball disponible dans la plupart des boutiques spécialisées ou les terrains de paintball.
- Avant et après l'utilisation du lanceur, vérifiez que toutes les vis sont bien serrées. Les vis peuvent se dévisser à cause vibrations. Une vis mal serrée peut être dangereuse et pourrait causer des blessures.
- Kingman recommande fortement que toute personne utilisant Ce produit ou a la portée de ce produit pendant son utilisation doit porter un masque de protection intégrale qui protège les yeux et le visage conçu spécifiquement pour la pratique du paintball. Il est également primordial de porter cette protection non seulement pendant le jeu mais aussi pendant la maintenance, la vérification du lanceur et même pendant du tir sur cible.
- Kingman rappelle aux usagers qu'il est votre responsabilité de protéger vos yeux et votre visage tout le temps, et ne sera pas tenu responsable d'accident par négligence en ne portant pas les protections adéquats.
- Ne tirez jamais ou ne visez jamais une personne qui ne porte pas les protections adéquates au paintball et qui ne se trouve pas sur un terrain conçu à la pratique du sport.
- Considérez toujours votre lanceur comme si il était chargé et armé.
- Ne regardez jamais dans le canon que le lanceur soit chargé ou déchargé.
- Toujours garder son lanceur éteint ou sur le mode "safe" jusqu'à son utilisation.
- Toujours démonter la source de gaz du lanceur avant tout démontage.
- Tirez exclusivement des billes de paintball de calibre 0.50cal avec ce lanceur.
- Assurez vous toujours que la culasse soit en position désarmée quand vous n'utilisez pas le lanceur.
- Utiliser un lanceur de paintball en dehors d'une zone faite pour le paintball peut être illégal, et peut être passible de poursuites si des dégâts ont été causés par son utilisateur.
- Transférez le manuel de l'utilisateur au nouveau propriétaire en cas de vente.
- Visite www.spyder50.com les mises à jour manuelle des utilisateurs.

MISE EN ROUTE

ATTENTION: Toujours garder son lanceur éteint ou sur le mode "safe" jusqu'à son utilisation.

1. Kingman recommande d'avoir le lanceur en position "SAFE" avant l'utilisation. Pour verrouiller la sécurité, pousser le bouton du coté "PUSH SAFE" de la poignée. Cela enclenchera la sécurité. Pour désengager la sécurité d'une manière sécurisée, pointer le lanceur dans une direction sans risque et poussez le bouton du coté "PUSH FIRE" de la poignée.
2. Placer le bouche canon sur le canon par précaution quand le lanceur n'est pas utilisé.
3. Attacher la bouteille de CO2 ou d'air comprimé à l'adaptateur. **CONSEIL:** Assurez-vous que la bouteille de CO2 ou d'air comprimé soit remplie avant de la monter au lanceur. Vissez la bouteille dans le sens des aiguilles d'une montre dans l'adaptateur jusqu'à ce que la valve s'ouvre. Si vous constatez une fuite entre la valve de la bouteille et l'adaptateur, remplacez les joints toriques uréthane. **NOTE:** Les joints toriques uréthane ne sont pas fournis dans le kit de réparation, ces joints ne sont pas faits pour la valve de la bouteille. **IMPORTANT:** Vous ne devriez jamais avoir à utiliser des outils pour monter ou démonter la bouteille de CO2 ou d'air comprimé sur l'adaptateur.
4. Attacher un coude et un chargeur électrique à la descente de bille (non représenté) **NOTE:** Remplissez le chargeur uniquement avec des billes de paintball de calibre 0.50cal
5. Armement du marqueur. Armez le marqueur en tirant la tirette d'armement vers l'arrière jusqu'à ce que la culasse en Venturi s'enclenche. **ATTENTION:** Si vous lâchez la culasse avant qu'elle ne s'enclenche, un coup pourrait partir.
6. Enlever le bouchon de canon. **PRECAUTION:** Si le bouton de sécurité est enclenché, le lanceur est en mode « live », appuyer sur la détente déclenchera le tir d'une bille. **IMPORTANT:** Toujours tester le lanceur dans une direction sûre ou dans une aire de jeu approprié et vous ne devrez que tester les capacités du lanceur.
7. Effectuez un TEST DE VELOCITÉ (fps). Tourner l'ajusteur de vélocité / guide ressort dans le sens des aiguilles d'une montre augmentera la vélocité (fps). **NOTE:** Votre marqueur est destiné à être utilisé uniquement sur un complexe de paintball avec les protections appropriées à la pratique du paintball. **IMPORTANT:** Kingman recommande l'utilisation d'un chronographe pour s'assurer que la vélocité du marqueur soit en dessous de 300 pieds par seconde (fps).
8. Le jeu terminé, retirez toutes les billes de paintball du chargeur puis retirez le chargeur de billes de paintball et le coude vertical du marqueur. **ATTENTION:** Il est possible qu'une bille de paintball se trouve dans la descente de billes; appuyez sur la détente à quelques reprises en pointant le marqueur dans une direction sûre pour vous assurer que le canon et la descente de billes soient vides.
9. Remplacez le bouchon de canon / chaussette à canon, sur le canon quand le lanceur n'est pas utilisé. Ceci évitera tout tir accidentel.
10. Kingman recommande de mettre le marqueur en position "SAFE" après utilisation.
11. Dévissez la bouteille de CO2/air comprimé de l'adaptateur C/A du marqueur. Dévissez dans le sens opposé des aiguilles d'une montre. **ATTENTION:** Ne jamais exposer une partie du corps non protégée sous le trou d'évacuation de CO2/air comprimé de l'adaptateur C/A lorsque vous enlevez la bouteille. Ceci peut entraîner des risques de brûlure venant de l'évacuation du gaz. **IMPORTANT:** Vous ne devriez jamais avoir besoin de recourir à l'utilisation d'outils pour détacher la bouteille de CO2/air comprimé.
12. Placez le marqueur dans un sac de paintball ou dans un endroit sûr. **CONSEIL PRATIQUE:** Due aux vibrations les vis peuvent se desserrer et se perdre. Assurez-vous de resserrer toutes les vis avant et après utilisation du marqueur. Il est conseillé de lubrifier le marqueur avant et après chaque utilisation, surtout lorsque le marqueur n'a pas servi pendant un long laps de temps. Ajoutez quelques gouttes d'huile pour marqueur de paintball sur le joint de marteau. (Voir guide de démontage/ remontage). Avant de ranger le marqueur, assurez vous d'avoir votre marqueur en position désarmée. Ceci évitera que le ressort principal ne perde sa tension.

IMPORTANT


- La vélocité peut varier selon l'altitude et les conditions climatiques
- Avant d'utiliser le lanceur il est impératif de procéder à un « test de sécurité de vélocité ». Pour cela utilisez un appareil appelé « chronographe de vélocité » spécifique au paintball disponible dans la plupart des boutiques spécialisées ou les terrains de paintball. **NOTE:** ce lanceur est conçu pour être utilisé à une vélocité inférieure à 300 pieds par seconde (fps). Ce produit ne doit pas être utilisé sur une personne à moins de 25 pieds.
- Ce lanceur de paintball peut contenir après le démontage de la bouteille de CO2 ou d'air comprimé un excédent de gaz toujours présent dans le lanceur, toujours enlever les billes du lanceur et tirer quelque coups pour vider l'éventuel excédent de gaz, en s'assurant de le faire prudemment.
- Ne jamais laissé monté une bouteille de CO2 ou d'air comprimé sur le lanceur si ce dernier n'est pas sous surveillance.

8 ÉTAPES POUR COMMENCER À JOUER

IMPORTANT: Lire les recommandations de sécurité et de fonctionnement avant de suivre les 8 étapes rapides pour commencer à jouer.




Assurez-vous que la sécurité soit sur ON



Insérez le dispositif de blocage du canon



Mettez vos lunettes de paintball et armez le marqueur



Retirez le dispositif de blocage du canon



Installez une bouteille de CO2 / d'air comprimé



Installez un chargeur de billes et remplissez-le




Déverrouillez la sécurité




Prêt à jouer et tirer

IMPORTANT: S'assurer que le marqueur est en MODE SÉCURITÉ et que le dispositif de blocage du canon est bien en place sur le marqueur après avoir JOUÉ.

CONSIGNE DE SECURITE SUR LA BOUTEILLE DE CO2/AIR COMPRIME



SAFE



WARNING: UNSAFE



DANGER

La bouteille de CO2 ou d'air comprimé peut partir avec assez de force pour causer des blessures graves ou la mort si la valve se détache de la bouteille. Toujours regarder la valve en devisant la bouteille, en s'assurant que la valve tourne avec la bouteille et ne reste pas sans bouger contre l'adaptateur on/off. Arrêter le démontage si la valve commence à se dévisser de la bouteille. Dans le doute, revisser la bouteille (sens des aiguilles d'une montre) et contactez une personne compétente pour la réparation.

CONSIGNE DE SECURITE SUR LA BOUTEILLE DE CO2/AIR COMPRIME

- Toute valve doit être installée et désinstallée par une personne compétente en pneumatique.
- Reportez vous au label sur la bouteille pour les dates de ré épreuve .Les bouteilles doivent être réévaluées périodiquement.
- Une utilisation, remplissage, conservation inadaptée à la bouteille peut provoquer la mort, des blessures ou / et des dégradation au matériel.
- Toujours garder les bouteilles hors de portée des enfants ou de personnes non expérimentées.
- Seulement les personnes ayant suivi un stage de remplissage avec la CGA Pamphlets P.1 et G-6.3 sont autorisées à remplir les bouteilles. Les Pamphlets sont disponible au près de l'association « COMPRESSED GAS ASSOCIATION » ou sur le site www.CGANET.com.
- Ne jamais modifier la bouteille d'aucune manière que ce soit.
- Ne JAMAIS exposer une bouteille sous pression à une température supérieure à 130F (54C)
- Une bouteille chauffée à une température supérieure à 250F (121C) doit être jetée ou ré évaluée en conformité avec le test défini dans le CFR-49
- La valve ne devrait jamais être détachée de la bouteille, demander immédiatement une assistance à une personne compétente si cela se produit.
- Toute bouteille incluse avec ce produit doit être utilisée exclusivement pour la pratique du paintball et rien d'autre.
- Vérifiez que le joint torique uréthane est bien présent sur la valve de la bouteille de CO2 ou d'air comprimé avant de monter la bouteille sur le lanceur. Si le joint torique est manquant, la bouteille se mettra à fuir du moment que la bouteille sera attachée au lanceur.
- Il est fortement conseillé d'utiliser exclusivement des joints torique uréthane.
- Ne jamais monter la bouteille de CO2 ou d'air comprimé en surpression.
- Evitez toute exposition directe de la peau au gaz purgé, en montant ou démontant la bouteille du lanceur.
- Ne jamais exposer la bouteille à des substances corrosives ou produits caustiques

MONTRE UNE BOUTEILLE DE CO2/AIR COMPRIME

Visser fermement la bouteille de CO2 ou d'air comprimé dans le sens des aiguilles d'une montre dans l'adaptateur C/A
CONSEIL: toujours vérifier que la bouteille de CO2 ou d'air comprimé soit pleine et que le joint uréthane soit présent sur la valve pour éviter des fuites.

IMPORTANT: vous ne devriez jamais avoir à utiliser des outils pour monter ou démonter la bouteille de CO2 ou d'air comprimé sur le C/A adaptateur

DEMONTRE UNE BOUTEILLE DE CO2/AIR COMPRIME

Dévisser la bouteille de CO2 ou d'air comprimé de l'adaptateur en tournant dans le sens inverse des aiguilles d'une montre. **CONSEIL:** après l'utilisation vous devriez toujours démonter la source de gaz de votre lanceur. Quand la bouteille est démontée de l'adaptateur on/off, un excédent de gaz est purge par le dessous. **PRECAUTION:** Ne jamais exposer la peau en dessous de l'adaptateur on/off où se trouve le trou d'évacuation lors du démontage. Ceci peut provoquer des brûlures de la peau au moment de la purge du gaz. **IMPORTANT:** vous ne devriez jamais avoir à utiliser des outils pour monter ou démonter la bouteille de CO2 ou d'air comprimé sur l'adaptateur on/off.

UTILISATION APPROPRIEE DU BOUCHON DE CANON

Le bouchon de canon est une partie essentielle à la sécurité de votre équipement .Le bouchon de canon est un outil servant à empêcher les billes de sortir du canon. Mal utilisé le bouchon de canon ne sert à rien.

BOUCHON DE CANON TYPE "CHAUSSETTE"

Placer la chaussette du bouchon de canon par dessus le bout du canon et tirez l'élastique pour l'accrocher à l'arrière du lanceur, puis, ajuster l'élastique de manière à ce que la tension soit suffisante pour arrêter une bille sortant du canon. **NOTE:** si l'élastique est trop long, vous pouvez faire des nœuds pour raccourcir l'élastique.

BOUCHON DE CANON TYPE "BOUCHON RIGIDE"


Inserez le bouchon de canon au bout de votre canon avant de monter la bouteille de gaz et de mettre des billes dans votre lanceur. Le bouchon de canon ne doit pas pouvoir s'enlever facilement.

NOTE: vérifiez toujours que les joints toriques ne soient pas usés ou encore coupé. N'enlevez le bouchon de canon que quand vous êtes prêt à jouer. Gardez toujours votre bouchon de canon sur votre lanceur après avoir fini de jouer et gardez-le, même après avoir vidé le lanceur des billes de paintball et démonté la bouteille de gaz de votre lanceur.

ATTENTION

Pensez à inspecter régulièrement votre bouchon de canon, si vous observez une usure, remplacez le immédiatement. Toujours avoir votre bouchon de canon sur votre lanceur pour prévenir un éventuel accident qui pourrait causer de blessures grave ou même la mort.


INSTALLATION/RETRAIT D'UN CHARGEUR DE BILLES



Fixer un chargeur de billes électronique ou à gravité au distributeur de marqueurs et serrer les vis de pression. Serrer les deux accessoires pour assurer une bonne fixation. N'utiliser que des billes de calibre 0.50 dans le chargeur.

Desserrer les vis du distributeur de marqueurs et retirer le chargeur de billes électronique ou à gravité. Lors du retrait du chargeur, s'assurer que toutes les billes soient retirées. **ATTENTION :** Il peut rester des billes dans le conducteur du marqueur ; donner quelques coups dans une direction sans danger pour vérifier que le canon et la culasse sont vides.

REGLAGE DE LA VELOCITE, AUGMENTER / DIMINUER



Pour AUGMENTER la vitesse FPS (feet per second = pieds par seconde) utilisez la clef six pans et tournez la pièce VELOCITY ADJUSTER/SPRING GUIDE dans le sens des aiguilles d'une montre.

Pour DIMINUER la vitesse, tournez dans le sens inverse des aiguilles d'une montre.

NOTE: la pièce VELOCITY ADJUSTER/SPRING GUIDE ne se démonte pas par l'arrière du bouchon de la pièce STRIKER PLUG

MISE EN GARDE

- La vitesse de ne doit jamais excéder 300 fps, une vitesse plus importante est dangereuse et peu causée de sérieuses blessures.
- Les lanceurs de paintball ne sont pas fait pour être utilisés contre des personnes à moins de 30 feet.
- Ne jamais pointer le lanceur en direction d'une personne qui ne porte pas une protection faciale adaptée à la pratique du paintball.
- Ne regardez jamais dans le canon à aucun moment que le lanceur soit chargé ou non.
- Utiliser un lanceur de paintball en dehors d'une zone faite pour le paintball peut être illégal, et peut être passible de poursuites si des dégâts ont été causés par son utilisateur.

BILLE COINCEE DANS LA DESCENTE DE BILLE

Dans l'éventualité où une bille serait coincée par la culasse et la bloquerai, suivez cette procédure pour débloquent la bille. La chambre de la bille est située juste avant le canon en dessous de la descente de bille. Avant d'essayer de débloquent la bille vous devez porter votre masque de protection. Assurez vous d'avoir mis le lanceur en position off ou enclenché la sécurité. Démontez la bouteille de CO2 ou d'air comprimé, enlevez le chargeur de billes, et assurez vous qu'il ne reste plus de billes dans le lanceur. Dévissez le canon du lanceur pour permettre à la bille coincée de sortir. Tirez avec une force suffisante sur la goupille de réarmement vers l'arrière jusqu'à débloquent la culasse. Si vous n'arrivez toujours pas par ce moyen à décoincer la culasse, une autre méthode consiste à prendre une tige de nettoyage droite et rigide ou bien une tige en bois et pousser la culasse vers l'arrière en poussant avec la tige depuis l'avant du lanceur en faisant attention que la surface en contact avec le devant de la culasse soit plat pour ne pas endommager la culasse ou l'alésage du corps. Après avoir débloquent la culasse d'une manière ou d'une autre, nettoyez la chambre de la bille et la culasse si nécessaire pour assurer des performances optimums.

IMPORTANT: ne regardez jamais dans le canon que le lanceur soit chargé ou non.

Toujours démonter la source de gaz avant d'entreprendre le décoincage de la culasse.

NOTE: Ne jamais utiliser une tige en métal pour pousser la culasse, cela pourrait rayer le corps ou la culasse.

NETTOYAGE DU MARQUEUR

DANGER: Ne pas regarder dans le canon du marqueur. Toujours porter des lunettes spécialement conçues pour les marqueurs de paintball, dès que vous manipulez votre marqueur.

IMPORTANT: Toujours mettre le marqueur en MODE SÉCURITÉ avant de le démonter. Retirer toutes les billes et toute source d'air éventuelle du marqueur avant d'effectuer les tâches de maintenance.

CONSEIL UTILE: Suivre ces étapes pour enlever la bille / nettoyer le marqueur, en cas de rupture de bille.

NETTOYAGE DU CANON ET DU CONDUCTEUR AVEC UNE RACLETTE

Utilisation d'une tige de nettoyage rigide (non fournie)


Si la culasse Venturi est en position non armée, vous devez réarmer le marqueur. Faire glisser la tige rigide vers le bas du canon jusqu'au conducteur du marqueur. Retirer ensuite la tige du canon. Ceci devrait nettoyer tout résidu

de peinture qui aurait pénétré à l'intérieur du marqueur. **CONSEIL UTILE:** S'assurer que le conducteur du marqueur est propre, sans fragments de cartouche de bille ni poussière. Répéter cette étape s'il reste encore des résidus de peinture.

Utilisation d'une tige de nettoyage pourvue d'un coton-tige (non fournie)

Dévisser le canon et faire glisser le coton-tige en partant de l'extrémité fileté, afin que le bout du coton-tige atteigne le bout du canon. Saisir le bout de la tige de nettoyage et tirer. Ceci devrait éliminer tout résidu de peinture qui aurait pénétré à l'intérieur du canon. **CONSEIL UTILE:** S'assurer que le conducteur du marqueur est propre, sans fragments de cartouche de bille ni poussière. Répéter cette étape s'il reste encore des résidus de peinture.

DEMONTAGE/REMONTAGE ET NETTOYAGE DES PIECES INTERIEURES ARRIERES



Part Names and Numbers describe in this section:

Top Cocking Knob (#STK010)

Venturi Bolt (#VTB050)

Striker Bolt (#STB003)

Striker Spring (#SPR017)

Striker Buffer (#STF002)

Striker Plug (#STP050)

Velocity Adjuster (#VTA050)

Receiver (#REC050/051/052/053)

NETTOYAGE ET DEMONTAGE RAPIDE

Tirer la goupille de réarmement TOP COCKING KNOB vers le haut. Cela désolidarise la culasse VENTURI BOLT du marteau STRIKER BOLT et vous pourrez ainsi tirer la culasse vers l'arrière et la sortir du lanceur. **CONSEIL:** retirer la culasse permet le nettoyage plus pratique à l'aide d'un « squeegee ». **NOTE:** vérifiez toujours que le trou du marteau soit sur le haut et qu'on le voit en entier quand on regarde par le dessus du corps du lanceur pour pouvoir connecter la goupille de réarmement qui lie la culasse au marteau. **IMPORTANT:** vérifiez toujours que le trou situé au milieu de la culasse en Venturi soit vers le bas pour autoriser le gaz de passer de la valve à la culasse pour propulser la bille, si le trou est vers le haut, les billes sortiraient avec une vitesse très basse.

DEMONTAGE DES PIECES INTERNES ARRIERES

ETAPE 1 tirez la goupille de réarmement vers le haut et tirez la culasse hors du corps.

ETAPE 2 utilisez un clef à molette pour dévisser le « Striker plug » à l'arrière du corps, permettant de sortir toutes les autres pièces hors du corps.

NOTE: assurez vous que le lanceur soit en position désarmé pour minimiser la pression du ressort de marteau afin que les pièces ne soient pas éjectées hors du corps,

ASTUCE: gardez votre pouce sur la pièce « STRIKER PLUG » afin relâcher les pièces doucement



ETAPE 3 Sortez les pièces dans l'ordre « striker plug », ressort de marteau et bumper.

ETAPE 4 faites glisser le marteau hors du corps.

CONSEIL: nettoyez l'intérieur du corps à l'aide d'une tige, nettoyez également le marteau et la culasse en remettant quelque gouttes d'huile sur le joint torique rouge du marteau.

IMPORTANT: il n'est pas nécessaire de démonter les pièces internes pour un entretien normal à moins que vous deviez changer le joint torique du marteau (striker O-ring)

REMONTAGE DES PIÈCES INTERNES ARRIÈRES



ÉTAPE 1 en premier, réinsérez le marteau en faisant attention de le mettre avec le joint torique rouge vers l'avant et le trou pointé vers le haut pour pouvoir se connecter avec la culasse.

NOTE: pour réinsérer le marteau, allumez le lanceur, et en même temps que vous appuyez sur le marteau, avec votre pouce, appuyez plusieurs fois sur la détente afin d'insérer le marteau jusqu'au fond. **NOTE:** le trou du marteau doit être situé vers le haut et visible depuis le dessus du corps pour permettre de connecter la culasse.

ÉTAPE 2 remettez le bumper avec le ressort de marteau passant par le milieu du bumper.


ÉTAPE 3 revissez fermement le striker plug à l'arrière du corps.

ÉTAPE 4 faite glisser la culasse vers l'avant en s'assurant que le trou du marteau soit aligné afin que la goupille de réarmement puisse se connecter, puis pressez la goupille de réarmement vers le bas et assurez-vous que la culasse soit bien connectée au marteau.

MISE EN GARDE: avant et après l'utilisation, vérifiez que toutes les vis soient bien serrées, une vis desserrée peut causer de sérieuses blessures.

Pour assurer un montage correct, suivez le schéma en regardant la position des composants. Une pièce mal montée causera des problèmes de fonctionnement du lanceur.

ACCÈS AU JOINT DE CULASSE ÉTAPE PAR ÉTAPE



Part Names and Numbers describe in this section:

C/A Adapter (#ASA026)
Vertical Screw (#SCRO31)
Vertical O-ring (#ORG025)
Vertical Adapter (#VRT036)
Cup Seal (#ITP020)
Valve Pin (#ITP021)
Valve Spring (#SPR018)
C/A Adapter Screw (#SCRO19)
Front Plug (#LPC050)
Foregrip Expansion Chamber (#FRG036)

L'accès au joint de culasse pour maintenance ou remplacement nécessite de retirer la prise avant et l'adaptateur vertical.

ÉTAPE 1 Dévisser les vis de l'adaptateur CA et desserrer entièrement le régulateur de l'adaptateur vertical.

ÉTAPE 2 Retirer l'adaptateur vertical en dévissant sa vis de fixation et veiller à garder un doigt sur la prise avant afin de l'empêcher de sortir brusquement. **NOTE:** La prise avant et l'adaptateur vertical sont tous deux maintenus en place par la vis de fixation de l'adaptateur vertical.

ÉTAPE 3 Retirer la prise avant, qui devrait sortir avec le ressort du clapet, le joint de culasse et la goupille du clapet.

ÉTAPE 4 Dévisser le joint de culasse de la goupille du clapet et le remplacer par celui fourni dans le kit de pièces de rechange.

ÉTAPE 5 Suivre les étapes précédentes dans l'ordre inverse pour remonter les composants correctement. S'assurer

que l'orifice de la vis de la prise avant est aligné avec celui de la vis de l'adaptateur vertical.

IMPORTANT: Toujours vérifier que toutes les sources d'air ont été retirées du marqueur et que tout air résiduel a été entièrement évacué avant d'effectuer toute opération de maintenance sur le marqueur.

NOTE: La maintenance ou le remplacement du joint de culasse ne doit être effectué(e) qu'en cas de fuite audible sur le conduit après le retrait de la culasse Venturi.

DÉPANNAGE

En cas d'éclatement des billes

1. Si la température est inférieure à 15 °C (59 °F) ou supérieure à 30 °C (85 °F), les billes peuvent devenir cassantes et ne pas supporter la vitesse des marqueurs et la température extérieure. Les billes ont une durée de vie et peuvent devenir trop fragiles pour être utilisées. Les billes peuvent changer de forme avec le temps et il est recommandé de les calibrer selon votre canon. Des fragments de cartouche de peinture sales ou cassés dans le canon peuvent provoquer des problèmes de réarmement du marqueur. L'utilisation d'une tige de nettoyage dans la partie supérieure du récepteur permettra d'enlever la plupart de ces fragments sales ou cassés.
2. Si deux billes se trouvent à l'intérieur du canon/conducteur en même temps et que le marqueur a été armé, les billes peuvent être éjectées du canon.
3. Si le chargeur de billes est trop chargé et qu'une bille est coincée à mi-chemin dans le marqueur, les billes risqueraient d'éclater.
4. La vitesse est trop élevée et doit être réduite à la bonne vitesse (fps).

Problèmes liés au réarmement

1. Il faut lubrifier le joint torique du percuteur. (VOIR DÉMONTAGE/MONTAGE ET NETTOYAGE DES PARTIES INTERNES ARRIÈRE).
2. Le joint torique du percuteur est endommagé ou manquant. Le remplacer par un nouveau joint torique de percuteur homologué Kingman. **NOTE:** Le joint torique du percuteur ne peut pas être remplacé par un autre type de joint torique.
3. La pression dans la bouteille est trop faible et il faut probablement la remplir à nouveau.
4. La présence de fragments de cartouche de peinture sales ou cassés dans le récepteur peut provoquer des problèmes de réarmement du marqueur. L'utilisation d'une tige de nettoyage dans la partie supérieure du récepteur permettra d'enlever la plupart de ces fragments sales ou cassés. Si ce problème persiste, retirer les parties internes du marqueur pour les nettoyer complètement. (VOIR DÉMONTAGE/MONTAGE ET NETTOYAGE OU PARTIES INTERNES ARRIÈRE).

EN CAS DE FUITE D'AIR

Dans le canon ou hors du cadre de la gâchette.

1. Le joint de culasse est en mauvais état et doit être remplacé. (VOIR LE GUIDE DE RETRAIT DU JOINT DE CULASSE)
2. Le rebord du corps du clapet est éraflé ou rayé et doit être remplacé. **NOTE:** Ne jamais retirer le corps du clapet, sauf si des réparations sont vraiment nécessaires.
3. Fuite d'air dans le récepteur et par le cadre de la gâchette. Le joint torique arrière du corps du clapet est endommagé et doit être remplacé.

Fuite d'air du tuyau


1. Si la fuite d'air se situe à l'extrémité opposée du tuyau, les raccords auront besoin d'être resserrés pour être bien ajustés.
2. L'extrémité femelle du tuyau doit être équipée d'une rondelle en plastique à l'intérieur du collier de serrage et doit être bien serrée. **IMPORTANT:** Le tuyau fourni a des extrémités femelles métriques. Il ne sera pas possible de le brancher à un raccord fileté américain 1/8" (NPT). En cas de mauvaise installation, les raccords et le tuyau risquent d'être endommagés.
3. Le joint torique en haut du Foregrip est endommagé ou doit être remplacé. **CONSEIL UTILE:** S'il est impossible de le remplacer par un joint en stock, vous pouvez le remplacer par un joint torique en uréthane.

LISTE DES PIECES DU OPUS™ / OPUS A™

ASA026	C/A Adapter (matte black)	SAB001	Safety Button
BAR051	Spyder Barrel Plug (.50 cal)	SAB002	Safety Button A
BAR050	1PCS Barrel (matte black) (.50 cal)	SCR002	M4 x 8 Screw (A) A
BLS036	Detent Cover (plastic)	SCR016	M5 x 12 Screw w/ washer (A) A
BLS050	Ball Stopper (.50 cal)	SCR017	M5 x 12 Screw (allen big head)
FND051	Clamping Collar (matte black) (.50 cal)	SCR018	M3 x 8 Screw (+)
FND050	Feed Neck (matte black) (.50 cal)	SCR019	M5 x 28 Screw C/A Adapter Screw (A)
FRG036	Foregrip Expansion Chamber (matte black)	SCR030	M4 x 12 Clamping Screw (A)
GRP003	Rubber Grip Cover (black)	SCR031	M6 x 16 Vertical Screw (A)
HSE011	Disconnect Hose (male x female) 4.5"	SCR032	M4 x 6 Ball Detent Screw (A)
HSF004	Plastic Washer	SCR033	M6 x 8 Valve Body Screw (A) (.50 cal)
HSF009	90° Male to Male Adapter (std x met) swivel	SER002	Sear (semi)
ITP020	Cup Seal (.50 cal)	SPR008	Sear Spring (semi)
ITP021	Valve Pin (.50 cal)	SPR011	Trigger Spring (semi)
ITP022	Valve Body (.50 cal)	SPR017	Striker Spring (.50 cal)
LPC050	Front Plug (matte black) (.50 cal)	SPR018	Valve Spring (.50 cal)
ORG002	O-ring #15 80	STB003	Striker Bolt (.50 cal)
ORG004	O-ring #11 80	STF002	Striker Buffer (.50 cal)
ORG025	Vertical O-ring #10 80	STK010	Top Cocking Knob (semi) (.50 cal)
ORG026	Striker O-ring #12.54 70 pu (.50 cal)	STP050	Striker Plug Threaded (matte black) (.50 cal)
ORG027	O-ring #14 80 (.50 cal)	TRF003	Polymer Trigger Frame
ORG028	Barrel O-ring #14 70 (.50 cal)	TRF004	Aluminum Trigger Frame A
* PAK009	Spare Parts Kit (.50 cal.)	TR5003	Double Trigger (semi)
REC050	Opus Receiver (blue)	VBT003	Bolt Locking Bearing
REC051	Opus Receiver (grey)	VBT004	Bolt Locking Spring
REC052	Opus-A Receiver (black) A	VBT013	Bolt Locking Screw
REC053	Opus-A Receiver (green) A	VBT050	Bolt w/ Locking Knob (.50 cal)
RPN004	Trigger Roll Pin (large)	VRT036	Vertical Adapter (matte black)
RPN005	Sear Roll Pin (med)	VTA050	Velocity Adjuster & Spring Guide (matte black) (.50 cal)
RPN006	Secondary Roll Pin (small)		

* Item Not Pictured (+) Cross-head Screw (A) Allen-head Screw A OPUS-A

SCHEMA ECLATE DU OPUS™ / OPUS A™



POLICE DE GARANTIE

Kingman garanti au client original ce produit pour une période de 1 ans à partir de la date d'achat, garantie pièce et main d'œuvre en cas de défaillance sous réserve que le produit est été utilisé dans des conditions normales. Toutes pièce électronique dans les lanceurs Spyder électronique sont garantie 6 mois à partir de la date d'achat. Kingman accepte de réparer ou remplacer à sa discrétion tout produit dans une période de temps raisonnable. Cette garantie ne couvre pas les joints toriques, cup seals, pile 9.6V rechargeable, chargeur de pile, rayures, les usures normales, toute modification, délavage normal de l'anodisation, et coups ou dommages à la suite de chocs. Le produit de sera pas garanti si un des technicien de Kingman prouve que le client est responsable de la panne ou de l'usure. Cette garantie ne couvre que les pièces d'origine. -Toute modification du produit ou de ses pièces d'origines entraînera l'annulation de la garantie ainsi que la responsabilité de Kingman. Tout dommage causé par de l'eau ne sera pas couvert. Les réparations sous garanties doivent être effectuées par un technicien de Kingman ou un technicien approuvé par Kingman. Pour que la garantie soit valide , le client doit retourner le coupon de garantie ci joint dûment complété, avec une copie du reçu du vendeur sous 15 jours après l'achat. Cette garantie n'est pas transférable. Les lanceurs de paintball ne sont pas remboursables. Cette garantie ne couvre pas les frais d'envoi, d'enlèvement ou encore les téléphones. Si le lanceur a besoin d'être réparé, le client emballera le lanceur et l'enverra avec le nom, l'adresse, le numéro de téléphone et une brève description du problème a l'adresse suivante:

KINGMAN GROUP

Attn: Tech Department
14010 Live Oak Avenue
Baldwin Park, CA 91706 U.S.A.
www.kingman.com

L'enregistrement de la garantie est aussi disponible sur le site Internet: www.spyder50.com

SUPPORT TECHNIQUE

Notre support technique est ouvert de Lundi à Vendredi de 8 heure à 17 heures (heure cote ouest des USA) et peut être joint au Tele: (626) 430 2300 Fax:(626) 851-8530

PATENT PENDING

Spyder calibre .50 recommande l'utilisation du Spyder Slate™ paintball calibre .50 et Rapid™ E-loader pour une performance optimum.



THE NEXT CHAPTER IN PAINTBALL.™

THE NEXT CHAPTER IN PAINTBALL.™

www.spyder50.com